



# Детализировка и лист запасных частей FROSP AF-9021



配件



No.	Description	No.	Description	No.	Description
1	Screw M6*45	32	O-ring 9*1.8	62	Flat volute spring
2	Spring washer 6	33	Valve stem sleeve	63	Spring core
3	Exhaust cap	34	O-ring 6.1*1.8	64	Head assembly
4	Screw M6*30	35	Push rod compression spring	65	Pin A4*20
5		36	Flat washer D=5	66	Magazine protection block
6	Cylinder head	37	Switch push rod	67	magazine
7	Balance valve gasket	38	O-ring 62*1.8	68	Screw M6*14
8	Air seal plug	39	nailhead	69	Screw M5*30
9	Balance valve group	40	Pin 4*20	70	
10	O-ring 50.3*3.55	41	Safety frame pressure spring	71	Aluminum magazine baffle
11	Piston assembly	42	Welded assembly of safety frame	72	Screw M5*12
12	O-ring 79.3*2.5	43	nut	73	Nut M5
13	●-ring 69.3*2.5	44	Locating press spring	74	Shank of hook
14	Air cylinder	45	Steel ball DW = 3	75	Hook handle torsion spring
15	O-ring 62.8*2.65	46	Flat washer D=6	76	Hook shank shaft sleeve
16	O-ring 92.5*2	47	Screw M6*10	77	
17	Tightening ring	48	Safety nipple	78	Dowel strip
18	Lower tightening ring	49	Screw M8*22	79	Aluminum magazine holder
19	Sealing ring	50	trigger	80	Nut M6
20	Cylinder pressure spring	51	Fuse holder	81	O-ring 11.2*1.85
21	Compression spring gasket	52	Pin 3*30	82	Pin 3*45
22	Cylinder head gasket	53	Rectangular washer 12.3*8*3	83	Bolt M8*16
23	Sealing gasket	54	O-ring 2.8*1.8	84	Gun handle sheath
24	Gun body	55	sphere	85	End cover gasket
25		56	Valve stem retainer	86	End cover
26	cushion	57	Switch base	87	Spring washer 5
27	Top bar compression spring	58	Switch lever	88	Screw M5*18
28	O-ring 4.5*1.8	59	Screw M6*16	89	O-ring 63.6*2.5
29	Ejector pin	60	Aluminum magazine protective cover	90	Pipe joint
30	O-ring 11.2*1.5	61	Locating pin	91	
31	Valve stem			92	gasket