



Parts List and Drawing

8016R-420 PARTS LIST

NO.	CODE	Description	NO.	CODE	Description
1	511120	O-RING 2.5X1.8	27	621040	LEG SPRING
2	511100	O-RING 12.2X1.75	28	322700	LOCK PAWL
3	511060	O-RING 15.5X1.75	29	421510	COVER
4	511110	O-RING 16.4X1.8	30	210840	FRONT COVER
5	511080	O-RING 16X1.25	31	322660	BACK COVER
6	511090	O-RING 8X2.6	32	322650	DRIVER BLADE
7	511050	O-RING 27.5X2.6	33	410620	BUMPER
8	511040	O-RING 31.5X2.65	34	110440	BODY
9	510390	O-RING 17X2.65	35	322720	SILENCER
10	322830	PIN	36	322640	CAP
11	640290	STRAIGHT PIN 3X24	37	410610	DAMPER
12	640310	STRAIGHT PIN 4X19.5	38	310440	CYLINDER
13	630300	WASHER	39	421420	CYLINDER SPACER
14	610490	BOLT M4X12	40	421450	VALVE GASKET
15	610500	BOLT M4X16	41	421460	VALVE CAP
16	610720	BOLT M4X14	42	421470	TRIGGER
17	310470	END CAP	43	310450	VALVE CYLINDER
18	621030	TENSION SPRING	44	421440	VALVE SHAFT
19	511130	O-RING 19.5X3	45	410640	INTERMEDIATE VALVE
20	322690	FEED BAR	46	322750	PULLEY
21	421430	PISTON	47	322670	PIN
22	421480	VALVE PIN	48	421490	STOP
23	322680	BACK NOSE ASSEMBLY	49	640170	ROLL PIN 3X28
24	421500	END PIECE	50	410630	RUBBER HANDLE
25	310460	COVER	51	640320	STRAIGHT PIN B4X29
26	421520	COVER	P1	D322651	DRIVER UNIT