


Взрыв-схема монтажного пистолета Walte PT-274 и PT-273



TOOL 273 PARTS LIST:

Pos.	Description	Drawing No.
1	Left Handle	273101
2	Right Handle	273103
3	Receiver	273210
4	Short Barrel	273330
5	Short Fastener Guide	273820
6	Short Baseplate	273810
7	Trigger Lever Pin	273107
8	Trigger Lever	273108
9	Trigger Lever Spring	273109
10	Trigger	273105
11	Slide Screw	273203
12	Slide	273201
13	Slide Spring	273202
14	Regulator Nut Spring	355603
15	Regulator Nut Pin	355602
16	Regulator Nut	273602
17	Regulator Bolt	273601
18	Firing Pin Mech.	273402
19	Pushing Pin	273401
20	Firing Pin Sear	273403
21	Firing Pin Sear Spring	454034
22	Firing Pin Complete	273410
23	Mech. Spring	273406
24	Firing Pin Spring	273405
25	Receiver Base	273501
26	Advance Lever Screw	355604
27	Advance Lever	273507
28	Advance Lever Spring	273503
29	Advance Lever	273502
30	Receiver Base Screw	273505
31	Plug Cover	273104
32	Cushing Handle	273103
33	Short Piston	273320
34	Piston Disk	273306
35	Short Rubber Returner	273305
36	Handle Screw	273106
38	Buffer Ring	273856
39	Spall Guard	273855
40	Spring Guide	273415

TOOL 274 PARTS LIST:

Pos.	Description	Drawing No.
1	Left Handle	273101
2	Right Handle	273102
3	Receiver	273210
4	Long Barrel	274330
5	Short Fastener Guide	273820
6	Long Baseplate	274810
7	Trigger Lever Pin	273107
8	Trigger Lever	273108
9	Trigger Lever Spring	273109
10	Trigger	273105
11	Slide Screw	273203
12	Slide	273201
13	Slide Spring	273202
14	Regulator Nut Spring	355603
15	Regulator Nut Pin	355602
16	Regulator Nut	273602
17	Regulator Bolt	273601
18	Firing Pin Mech.	273402
19	Pushing Pin	273401

TOOL 274 PARTS LIST (CONT.):

Pos.	Description	Drawing No.
21	Firing Pin Sear Spring	454034
22	Firing Pin Complete	273410
23	Mech. Spring	273406
24	Firing Pin Spring	273405
25	Receiver Base	273501
26	Advance Lever Screw	355604
27	Advance Lever Spacer	273507
28	Advance Lever Spring	273503
29	Advance Lever	273502
30	Receiver Base Screw	273505
31	Plug Cover	273104
32	Cushing Handle	273103
33	Short Piston	273320
34	Piston Disk	273306
35	Long Rubber Returner	274305
36	Handle Screw	273106
38	Buffer Ring	273856
39	Spall Guard	273855
40	Spring Guide	273415