

**US(ALM)series** *NOTE: When ordering spare parts.Please state the part name and part number.*

No.	Part NO.	Name	PCS	No.	Part NO.	Name	PCS
1	52011	Hammer Cap Hammer (71)	1	28	15151	Nose Plate (71)	1
	52010	Hammer Cap Hammer (80 & 95 & A11 & 50)	1		18150	Nose Plate (80)	1
2	90087	O-Ring	1	29	15150	Nose Plate (95 & A11 & 50)	1
3	90000	O-Ring	1		17161	Magazine (71)	1
4	90001	O-Ring	1		18161	Magazine (80)	1
5	17025	Piston Ram Assembly (71)	1		15161	Magazine (95 &50)	1
	18020	Piston Ram Assembly (80)	1	11161	Magazine (A11)	1	
	15020	Piston Ram Assembly (95 &50)	1	30	93001	Hex. Soc. FT HD Screw	1
	11020	Piston Ram Assembly (A11)	1	31	98002	Hex. Soc. FT HD Screw	2
6	90000	O-Ring	1	32	18212	Magazine Retainer	1
7	90015	O-Ring	1	33	51213	Air Silencer	1
8	18045	Cylinder (71)	1	34	18171	Pusher Spring	1
	18040	Cylinder (80 & 95 & A11 & 50)	1	35	17186	Magazine Cover (71)	1
9	18050	Bumper	1		18181	Magazine Cover (80)	1
10	18061-1	Trigger Valve Set	1		15181	Magazine Cover (95 & 50)	1
11	18071	Trigger Valve Spring	1		11181	Magazine Cover (A11)	1
12	90055	O-Ring	1	36	52070	Pusher (71)	1
13	18090	Trigger Valve	1		18190	Pusher (80)	1
14	90006	O-Ring	1		15190	Pusher (95 & 50)	1
15	90008	O-Ring	1		11190	Pusher (A11)	1
16	18310	Trigger Valve plate	1	37	18200	Rear Magazine Bumper	1
17	90005	O-Ring (1007)	1	38	18291	Pin	1
18	90033	O-Ring (1018)	1	39	18340	Latch Bracket	1
19	90009	O-Ring	1	40	95001	E-Ring	1
20	18110	Trigger Valve Stem	1	41	18322-1	Automatic adjust switch kit	1
21	90033	O-Ring (1018)	1	42	52030	Pin	1
22	18130	Trigger Valve Guide	1	43	18240	Seal	1
23	90007	O-Ring	1	44	52040	Trigger	1
24	91013-1	Hex.HD Soc Screw + Spring Washer	2	47	94001-1	Air Plug	(1)
25	18332	Seal Retainer	1	48	18281	Magazine Latch	1
26	91001	Hex.HD Soc Screw	2	49	18271	Magazine Latch Spring	1
27	17146	Nose (71)	1	50	95002	E-Ring	1
	18140	Nose (80)	1	51	18590	Gun Body	1
	15140	Nose (95 &50)	1	52	97003	Nut	2
	11140	Nose (A11)	1				





